


# MX800 Series



## Parts List



**Replacement parts may no longer be available**

# MX800 Series

## Parts List

REF. NO.	PART NO.	DESCRIPTION
1	----	Plate, Escutcheon
2	<b>3205933J02</b>	Seal, Switch
3	<b>0305941K04</b>	Screw, Control Top; #4-40 Captive
4	----	Lockwasher, #4
5	----	"O" Ring
6	<b>0105957K69</b>	Lower Housing Kit (includes items 97 & 98)
7	<b>6405473N01</b>	Baseplate
8	<b>5505727N01</b>	Latch, Battery
9	<b>4105944K01</b>	Spring, Latch
10	<b>3905421C13</b>	Contact, Battery
11	<b>0305941K02</b>	Screw, Baseplate; #4-40
12	<b>3205082E24</b>	"O" Ring
13	<b>4605945K03</b>	Bushing, B+
14	<b>040002625</b>	Lockwasher, #2
15	<b>0400009761</b>	Lockwasher, #4
16	<b>0705830C02</b>	Support, Contact
17	<b>0300138651</b>	Screw, #2-56 x 1/8"; Phillips, Panhead
18	<b>3205082E11</b>	"O" Ring
19	----	Contact, B+
20	<b>NTN5206C</b>	Upper Housing Kit, with 2-pos rotary switch
	or	
	<b>NTN5205C</b>	Upper Housing Kit, with 16-pos rotary switch
21	<b>0105952M69</b>	RF Switch Assembly (includes items 22 & 106)
22	<b>0405483P01</b>	Washer, RF Jack
23	<b>0205578M01</b>	Nut, Stud
24	<b>4305577M01</b>	Stud
25	<b>3205472P07</b>	"O" Ring, Stud
26	<b>3205639F03</b>	Gasket
27	<b>0300140383</b>	Screw #2-56 x 9/16"; Phillips, Panhead
28	<b>0205588M01</b>	Nut, Antenna Seal
29	<b>0905771F02</b>	Pin, Coaxial
30	----	Not Used
31	<b>3905698N01</b>	Switch, Control
32	<b>6405187P01</b>	Plate, Control Switch
33	<b>0300136782</b>	Screw, #2-56 x 3/16"; Phillips, Panhead
34	----	Bushing, Antenna (not field replaceable; order item 20)
35	<b>1505673C03</b>	Connector, Side (J601)
36	<b>8505241U06</b>	Antenna, 800 MHz Whip
	or	
	<b>NAF4000B</b>	Antenna, 800 MHz Dipole
37	----	Control Flex Assembly with 2-position Rotary Switch (includes items 38-44, 114, & 115)
	or	
	----	Control Flex Assembly with 16-position Rotary Switch (includes items 38-44, 114, & 115)
38	<b>0905675C01</b>	Socket, Side Connector
39	<b>0905463Q01</b>	Connector, 20-Pin (J1)

REF. NO.	PART NO.	DESCRIPTION
40	----	Resistor – not available (See Electrical Parts List - R613)
41	----	Resistor – not available (See Electrical Parts List - R605)
42	----	Potentiometer – not available (See Electrical Parts List - R601)
43	<b>4005640Q08</b>	Switch, Rotary
44	<b>0200140458</b>	Nut, Volume Switch
45	----	Frame Assembly – not available (includes items 46-49)
46	----	PCB, PTT
47	----	Contact, Snap-Dome (not field replaceable; order item 45)
48	----	Seal, Dome (not field replaceable; order item 45)
49	----	Insulator, B+ (not field replaceable; order item 45)
51	----	Insulator, Logic (not field replaceable; order item 50)
52	----	Insulator, RF (not field replaceable; order item 50)
53	----	Standoff (not field replaceable; order item 50)
54	----	Screw, #2-56; Phillips, Panhead
55	<b>0305731J06</b>	Screw, #2-56; Phillips, Panhead
56	<b>NTN5108A</b>	Rear Shield Kit (includes item 57)
57	----	Insulator, Rear (not field replaceable; order item 56)
58	<b>NTN5646B</b>	Front Shield Kit (includes items 59-63 & 100)
59	----	Microphone (See Transceiver Board Parts List - MK501) – not available
60	----	Not Used
61	----	Speaker (See Transceiver Board Parts List - LS501) – not available
62	<b>4205790T01</b>	Boot, Microphone
65	<b>4205474P01</b>	Clip, B+
66	<b>0905006P01</b>	Plug, Coax; RF
68	<b>8405758N03</b>	Interconnect, Display
69	<b>3305206P01</b>	Label, Emergency
70	<b>3605295P01</b>	Knob, Volume Switch
71	<b>3605295P02</b>	Knob, Rotary Switch
72	<b>0305480E02</b>	Screw Set; #4-40 x 3/32"
73	<b>4210219A55</b>	E-Clip, Front Cover
74	<b>3205082E66</b>	"O" Ring, Control Top
75	<b>3205082E67</b>	"O" Ring, Front Cover
76	<b>1305711N10</b>	Escutcheon, 1-16
77	<b>3205606P01</b>	Seal, Side
78	<b>0300136783</b>	Screw, #2-56 x 5/16"; Phillips, Panhead
79	<b>0300139444</b>	Screw, #2-56 x 5/32"; Phillips, Panhead
80	----	Front Cover Kit, 15-key (includes items 81-90)
	or	
	<b>NTN5712A</b>	Front Cover Kit, Plain (includes items 82 & 83)

REF. NO.	PART NO.	DESCRIPTION
82	<b>1305954N09</b>	Escutcheon, Front Cover, 15-Key
	or	
	----	Escutcheon, Front Cover, Plain
83	<b>4205842R01</b>	Retainer, Front Cover
84	<b>6405761S01</b>	Plate, LCD Back-up
85	<b>2805397L09</b>	Elastomer, LCD
86	<b>1305955N01</b>	Bezel, LCD
87	----	Display Board Kit, with LCD/LED (not field replaceable; order item 80)
88	----	Light Pipe, LCD (not field replaceable; order item 80)
89	----	Shield, Static (not field replaceable; order item 80)
90	----	Keypad, 15-key (not field replaceable; order item 80)
91	<b>4505369Q01</b>	Lever, PTT
92	<b>3205853H02</b>	Gasket
93	----	Pad, RF
94	----	Not Used
95	----	Felt, Speaker (not field replaceable; order item 20)
96	----	Grille, Upper Housing (not field replaceable; order item 20)
97	----	Actuator, PTT (not field replaceable; order item 6)
98	----	Retainer, PTT (not field replaceable; order item 6)
99	<b>1105668K35</b>	Pad, Urethane
100	<b>1405784P01</b>	Insulator, Front
101	----	Nut, Retainer
102	<b>1405664J01</b>	Insulator, Plunger
103	<b>4405829J01</b>	Plunger, RF Switch
104	<b>4105836J01</b>	Spring, RF Switch
105	<b>1405787C01</b>	Insulator, Spring
106	<b>0905006P02</b>	Socket, Coax; RF (P4)
107	<b>3205082E25</b>	"O" Ring, Port
108	----	Seal, Port
109	<b>3205473P04</b>	"O" Ring, Side Seal
110	<b>NTN5023A</b>	Retainer, Side Seal (Optional)
111	----	Screw, Captive; #6-32 x 0.19" (Optional)
113	----	Pin, Stop
114	----	Nut, Rotary Switch
115	----	Washer, Retaining
116	----	Not Used
117	----	Pad, Urethane; Center Shield (not field replaceable; order item 50)
118	----	Washer, Doubled

**Cancelled Product MX800:  
Aftermarket support criteria has  
been met for spare parts. Items  
may no longer be available.**

# MX800 Series

## Portable Accessories

### Chargers

#### Single Unit Chargers

Single Unit Chargers are best suited for small system users, or users without centralized charging facilities. They are capable of charging batteries while they are on or off of the radio. When the battery is fully charged, a visual indication is given and the charger automatically reverts to a trickle charge rate. Actual charging time varies directly with battery capacity.



NLN8858A

**NLN8858A** Rapid Charge, 117 Volt

#### Adapter Kit

**NTN4529A** Adapter Kit, for 6-Unit Charger (for Wall or Rack Mount Applications)



NTN4529A

### Battery Optimizing System II (BOS II)



WPLN4124AR

No other battery analyzer matches the speed, accuracy, and versatility of the Battery Optimizing System II. Ideal for large fleet, public safety, and all other users who rely on their battery performance. Now with increased power, more sophisticated programming options, and easier to use navigation paths, optimizing your batteries was never easier. Key features include:

- Support for NiCd, NiMH, Li-ion, and SLA batteries
- 100 watt power supply and programmable from 100 mA to 4 amps per station
- Interchangeable adapters accommodate all major brands
- Includes a variety of user programs and allows for customizable programming
- Proprietary recondition cycle restores NiCd and NiMH batteries
- Increased processing power and testing resolution – including a three minute Quicktest that measures the batteries State of Health (SoH)
- Printer output for reports and labels
- Three year warranty

**WPLN4124AR** BOS II, Four-Station, 100-240V AC (US line cord)

**WPLN4125AR** BOS II, Four-Station, 100-240V AC (UK/Euro line cords)

#### BOS II Adapter

**RL-71223** Standard Adapter for MX800

# MX800 Series


## Portable Accessories

### Battery Maintenance System<sup>plus</sup> (BMS<sup>plus</sup>)

Using interchangeable battery adapters (sold separately), the BMS<sup>plus</sup> is capable of charging and discharging, analyzing, conditioning and cycle test on batteries; tracking battery voltage and capacity (mAh). The BMS<sup>plus</sup> offers a 3 year warranty. Its easy-to-use design supports hundreds of 2-way, cellular, and camcorder batteries with printer port\* (Serial-RS-232C port – uses female 9-pin to male 25-pin cable).

**WPLN4079BR** Six-Station, 110V AC, 50/60 Hz

**WPLN4080BR** Six-Station, 230V AC, 50/60 Hz



WPLN4079BR

### BMS<sup>plus</sup> Adapter

**TDN9451A** Standard Adapter for MX800

### Carrying Accessories

#### Carrying Cases

A variety of carrying accessories are available for your comfort and convenience. The carrying cases are available in sizes designed to fit your radio & battery and permit audio to be heard clearly.



NTN4968A

#### Swivel

**NTN4968A** Carry Case and Swivel Belt Loop Holder, For Medium Capacity Battery (Order Velcro T-Strap Separately)

**NTN4969A** Carry Case and Swivel Belt Loop Holder, For High Capacity Battery (Order Velcro T-Strap Separately)

#### Carry Holder

**NTN4350A** Carry Holder with Belt Loop, For All Models



NTN4350A

\*Compatible with the STAR Micronics SP200 series printers, available from any STAR Micronics distributor, and other printers with STAR emulation.

# MX800 Series

## Portable Accessories

### Carrying Accessories

#### T-Strap

**4205713P02** Nylon, Velcro, for all models



4205713P02



NTN4971A

#### Full Cover

**NTN4971A** Full Cover, Velcro, for all models

#### Belt

**4200865599** 1.75" Belt, for all models



4200865599

#### Carrying Strap

**NTN5243A** Carrying Strap, for all models



NTN5243A

#### Belt Loop

**4205857B01** 2" Belt Loop, for Swivel Case

### Audio Accessories

#### Remote Speaker Microphone

Remote speaker microphones allow the user to talk and listen without removing the radio from its belt carry case or charger. It has a top-ported speaker for improved audio reception and audio input.

**\*NMN6176A** Remote Speaker Microphone with Coil Cord, Clip Back, 2.5 mm Earpiece Jack and Earpiece (NTN4742A)



NMN6176A

**\*NMN6177A** Remote Speaker Microphone with Coil Cord and Clip Back

#### Public Safety Remote Speaker Microphone

This microphone is very similar to the remote speaker microphones, as it is weatherized, and has the top-ported speaker for better audio. There is an antenna for improved coverage.

**\*NMN6175A** Public Safety Remote Speaker Microphone, with Clip Back, 800-900 MHz Antenna Included



NMN6175A

\* Intrinsicly safe

# MX800 Series

## Portable Accessories

### Audio Accessories

#### Epaulet Strap

Black leather epaulet straps secure remote speaker microphone to epaulet of shirts or jackets and attach around cord. Allows reliable communications in hostile environments with velcro or clip style strap.

**RLN4294A** Epaulet Strap, Velcro

**RLN4295A** Epaulet Strap, Small Clip

**NTN4742A** Earpiece without Volume Control

**NTN4664A** Three wire surveillance accessory with earpiece microphone, and push-to-talk as separate pieces.



RLN4294A



RLN4295A

#### Ear Microphone System

This compact unit picks up the voice through bone vibrations in the ear canal. Ideal for use in high noise environments. Available in PTT or Voice-activated (VOX) capabilities for total hands free communications. Order Interface Module separately.

**\*BDN6677A** Ear Microphone for Standard Noise Levels (up to 95 db), Black



BDN6677A

**\*BDN6678A** Ear Microphone for Standard Noise Levels (up to 95 db), Beige

**\*BDN6641A** Ear Microphone for High Noise Levels (up to 105 db), Grey



BDN6641A

### Audio Accessories

#### Interface Module

**\*BDN6644B** Push-To-Talk Only Interface Module

#### Optional Accessories

**\*0180358B38** Remote Push-To-Talk Ring Switch

**0180300E25** Earguard with Adjustable Loop; secures ear mic in ear



0180358B38

**0180358B32** Earholder, Black, Size Small; secures ear mic in ear

**0180358B33** Earholder, Black, Size Medium; secures ear mic in ear

**0180358B34** Earholder, Black, Size Large; secures ear mic in ear

**0180358B35** Earholder, Clear, Size Small; secures ear mic in ear

**0180358B36** Earholder, Clear, Size Medium; secures ear mic in ear

**0180358B37** Earholder, Clear, Size Large; secures ear mic in ear



0180358B33

**4280369E44** Replaceable Belt Clip with Screws

**5080358B28** Eartips, Black, Size Medium (10 per pack)

**5080358B29** Eartips, Black, Size Large (10 per pack)

**5080358B30** Eartips, Beige, Size Medium (10 per pack)

**5080358B31** Eartips, Beige, Size Large (10 per pack)

\* Intrinsicly safe

# MX800 Series



## Portable Accessories

### Audio Accessories

#### Headsets

All headset accessories include adapter cables and can be plugged directly into radio. No additional equipment is required.

Low to moderate noise level (less than 100 dB) lightweight headset with Electret condenser microphone and single speaker.

*NOTE: Cannot be worn with headgear.*

**BDN6350A** In-line push-to-talk switch

**BDN6351A** Pendant-thumb push-to-talk switch

High noise level (to 115 dB) noise-attenuating headset with military noise-cancelling microphone and dual speaker. *NOTE: Cannot be worn with headgear.*

**BDN6358A** In-line push-to-talk switch

**BDN6356A** Body/foot switch that can be belt mounted

High noise level headset (up to 115 dB) with bone conduction microphone and dual speaker. *NOTE: for use with respirator or face mask kit.*

**BDN6314A** Body/foot switch that can be belt mounted

### Audio Accessories

High noise level headset (Up to 125 dB) with noise-cancelling microphone and push-to-talk switch located on earcup. Vox module contained within headset on voice activated units. Intrinsically safe.

*NOTE: Can be worn with or without hardhat or fire helmet.*

**BDN6638A** Adapter Cable for BDN6645, BDN6635, and BDN6636

**BDN6645A** Push-To-Talk Headset with Boom Microphone; Requires Adapter Cable BDN6638A



**BDN6645A**  
(Shown with adapter cable BDN6638A)

**BDN6635B** Voice-Activated Headset with Boom Microphone; Requires Adapter Cable BDN6638A; includes 110V Charger



**BDN6635B**  
(Shown with adapter cable BDN6638A)



**BDN6636B**  
(Shown with adapter cable BDN6638A)

**BDN6636B** Voice-Activated Headset with Throat Microphone; Requires Adapter Cable BDN6638A; Includes 110V Charger

**0180357B05** Spare VOX Headset Charger 110V

## **MX800 Series**

## *Portable Accessories, Antennas*

### **Audio Accessories**

#### **Helmet Kits**

The following DO NOT include headgear. *NOTE: All helmet and face mask kits require a radio cable assembly (order separately).*

Industrial/Police helmet kits for Bullard (Industrial) headgear with military noise-cancelling microphone.

**BDN6275A** Single Speaker

Bell BT600 1/2 Shell headgear with military noise-cancelling microphone (cable assembly required, order separately)

**BDN6362A** Single Speaker (Police)

#### **Cable Assemblies**

*NOTE: All helmet kits require one of the following cable assemblies:*

**BDN6315A** Cable assembly for Police Radio helmet kit with transmit switch, volume control, microphone electronics and a push-to-talk jack built into a belt mounted control box

**BDN6292A** Cable assembly for Police Radio helmet kit with handlebar push-to-talk switch for belt mounted control box (only applies to BDN6315A)

### **Portable Antenna**

#### **Dipole Antennas**

Dipole molded antennas are injection molded in lasting polyurethane. The wide skirt at the bottom of the connector protects against damaging environmental elements. The dipole antenna is ideal when strong and solid signal clarity is demanded.

#### **NAF4000B**

Dipole, 806-869MHz, 8"





# MX800 Series

## Batteries, Service Aids

### Portable Batteries

#### Nickel-Cadmium Premium

Part Number: **NTN4326A**

Volts: 7.5

Avg. mAh: 1300

Height: 2-7/16"

Intrinsically Safe: No



NTN4326A

Part Number: **NTN4327C**

Volts: 7.5

Avg. mAh: 1800

Height: 3-11/16"

Intrinsically Safe: No



NTN4327C

Part Number: **NTN4500A**

Volts: 7.5

Avg. mAh: 1800

Height: 3-11/16"

Intrinsically Safe: Yes



NTN4500A

Part Number: **NTN4534A**

Volts: 7.5

Avg. mAh: 1300

Height: 2-7/16"

Intrinsically Safe: Yes

### Service Aids

#### Battery Eliminator

Allows use of external power supply to power radio.

**RTL4199A** Battery Eliminator



RTL4199A

#### Battery Block Adapter

Transceiver can be connected to the battery eliminator with this adapter so it remains functional when out of the radio.

**RTL4206A** Battery Block Adapter



RTL4206A

#### RF Adapter Cable

Control the radio locally while taking transmitter measurements by attaching this adapter to the universal side connector.

**RTK4087A** RF Cable Adapter



RTK4087A

#### SMA to BNC Adapter

Make transmitter measurements while the portable is connected to the portable test set. The adapter connects the antenna jack.

**5880384G68** SMC to BNC Adapter

# MX800 Series

## Service Aids, Manuals

### Service Aids

#### Radio Interface Box

Links radio programming cable and computer interface together. Provides required voltage shift to enable communications between radio and computer. Requires computer interface cable, radio test and programming cable, and 9 volt snap type battery (6082728J01), order separately.



RLN4008E

**RLN4008E** Radio Interface Box

#### Computer Interface Cable

Used to connect computer's serial adapter to Radio Interface Box.

**3080369B71** Cable, RIB to 25 pin D

**3080369B72** Cable, RIB to 9 pin D



3080369B71



0180357A57

#### Wall Mounted Power Supply

Used to supply power to radio interface box RLN4008E.

**0180357A57** Wall Mounted Power Supply, 110 Volts

**0180358A56** Wall Mounted Power Supply, 220 Volts

### Service Aids

#### Programming Software

Utilizing your personal computer, this software enables you to add or reprogram frequencies as your requirements change. Compatible with IBM XT, AT, MODEL 30, 50, 60, and 80. Requires interface box and appropriate cables, must be ordered separately.

**RVN4073B** Programming Software

### Manuals

**6881064C40**

Service Manual

**6881064C35**

Operating Instructions

**0180305J46**

Ear Microphone System and Temple Transducer CD-ROM

Over 7 million customers have made MyRadioMall.com America's #1 choice when it comes to dependable and reliable Motorola Communications at fantastic prices.

We are now celebrating our 12th year of online service and the best is yet to come.



Advanced Radio Systems, Inc  
8726 NW 26 Street #6  
Miami, Florida 33172  
Voice Numbers: 305-884-1795  
Toll Free: 1-866-900-Mall (6255)  
Fax Number: 305-884-1985

12/25/2006