

SPECTRA Motorcycle Radio Parts List 0 0 2 Θ 0





Radio Enclosure Kit

REF.		
NO.	PART NO.	DESCRIPTION
1	0484336M01	Lockwasher; 4 used
2	0484338M01	Washer, flat; 8 used
3	0300040M08	Screw; 4 used
4	0384208M16	Screw; 4 used
6	0300007467	Screw (8-18 x 3/8); 18 used
7	5583818F01	Catch, lock
-		Adapter; 4 used
-		Ring, retaining
-	4583015P01	Cam, lock
-	5583817F01	Lock
13		Hinge

REF.		
NO.	PART NO.	DESCRIPTION
-		Rivet; 10 used
14		Enclosure Mounting Hardware
		(see MXW6804)
16	0380114M02	Screw M5 x 0.8 x 10 mm); 4 used
17	0384244C06	Screw, wing; 4 used
18	0780086N02	Trunnion
19		Lockwasher, external tooth; 8 used


NON-REFERENCED ITEMS

(from HLN6168B and HLN6169B)

0380077M01 Screw, hex socket











Control Head Mounting Parts

REF.		
NO.	PART NO.	DESCRIPTION
-		Motorcycle Hardware Kit SECURENET
-		Motorcycle Hardware Kit
1	3880064P01	Cap, SECURENET connector
2	0310945A11	Screw, tapping (P3.12 x 1.27 x 8.0); 2 used
3	0380077M01	Screw, front mount; 4 used
5	0483045H01	Washer, thrust; 2 used
7	3080010R02	Cable, accessory
8	1580293L02	Housing, back remote rework
9	1580062P07	Housing, front remote, SECURENET
10	3280063P01	Gasket, SECURENET
11	3280231M01	Gasket
12	3280289L02	Gasket, housing
13	4380128N01	Spacer, trunnion; 2 used
15		Control-head Cable, 22-conductor
-		Motorcycle Mounting Kit
16	0780200P01	Bracket, control head/ speaker mounting
17		Nut, hex (M5 x 0.8-6H x 8.87); 6 used
18	0400007652	Lockwasher #10 ext; 19 used
19	0380114M05	Screw, machine (M5 x 0.8 x 30 mm); 2 used
20	0380114M04	Screw, machine (M5 x 0.8 x 16 mm); 2 used
21	0780020R01	Bracket, accessory connector
22		Washer (0.234 x 0.5 x 0.048); 4 used

	REF. NO.	PART NO.	DESCRIPTION
-		.,	520011111011
	23	0307644M19	Screw, machine (8-32 x 7/16); 4 used
	25	0200001355	Nut, hex (8-32 x 5/16 x 1/8); 4 used
	26	0780201P01	Bracket, extension
	27	0380114M03	Screw, machine (M5 x 0.8 x 12 mm); 2 used
	28		Microphone and Coiled Cord Speaker
	29		(see exploded view)
	30	HLN9073	Spring & Bracket Eyelet (HLN5391A)
	31	0384244C06	Screw, wing; 5 used

NON-REFERENCED ITEMS

0300138015	Self-drilling screw; 2 used*		
0312002C01	Self-drilling screw*		
0780257N01	Back-up plate*		
2900824456	Lug*		
0780127N02	Trunnion, remote**		
1580062P04	Housing, front remote		


NOTES:

- * These parts are provided in hang-up clip kit for mounting the hang-up clip on surfaces that are not metallic and/or are not grounded to the motorcycle chassis.
- ** Used to mount control head when speaker and control head are mounted separately.










SPECTRA Motorcycle Radio



Parts List



Weather-Resistant Speaker

REF.			REF.		
NO.	PART NO.	DESCRIPTION	NO.	PART NO.	DESCRIPTION
1		Cloth Grille	12	3206849K01	Gasket
2	4083477E03	Switch, toggle, SPST	13	3083155H01	Cable, 2 conductor
3	3910184A45	Contact, plug; 2 used	15	1510183A18	Housing, connector, 2 contact
4	4282018H05	Cable Retainer	17		Washer
5	3206682F01	Seal, toggle switch	18	3280000S01	Gasket, speaker
6	0300140001	Screw, tapping (6-19 x 7/8)	19		Capsert; 4 used
7	0384244C06	Screw, wing, black shadow			
8	5084561B08	Speaker, 5-inch, 30W	NON-REI	FERENCED ITEMS	S
9		Gasket		0611086A27	Resistor, 47 ohms, ±5%, 1 watt
10	1300133M05	Bezel		0780200E01	Trunnion, bracket, speaker (not shown)
11	1580099R02	Housing, speaker, weather-resistant		0312002B14	Screw, self-drilling (10-16 x 1.0); 3 used



SPECTRA Motorcycle Radio

Accessories, Service Aids, Tools



Microphone & Speaker

HMN1062B Weather Resistant Palm Microphone **HSN6003B** Weather Resistant Speaker

Service Aids

Computer Interface Cable

Used to connect computer's serial port to Radio Interface Box (RIB).

3080369B71 Computer Interface Cable; RIB to 25 pin D 3080369B72 Computer Interface Cable; RIB to 9 pin D

Radio Interface Box

Links radio programming cable and computer interface together. Provides required voltage shift to enable communications between radio and computer. Requires computer interface

cable, radio programming cable and a 9 volt snap type battery (6082728J01) or wall mount power supply; order separately.

RLN4008E Radio Interface Box

0180357A57



RLN4008E

Wall Mounted Power Supply

Used to supply power to Radio Interface Box.

0180357A57 Wall Mounted Power Supply (110 volts)

0180358A56 Wall Mounted Power Supply (220 volts)

Service Aids

Programming Software

This software enables you to add or reprogram frequencies as your requirements change. Compatible with IBM XT, AT, Model 30, 50, 60 and 80. Requires Radio Interface Box and proper cables; order separately.

RVN4001N Programming Software, includes 3-1/2" diskette, manual, binder, and storage box.

Program/Test Cable

Acts as a link between RIB and radio; required to program radio.

3080369B73 Program/Test Cable

Service Tools



Torque Screwdriver

Measures the amount of torque being applied. Recommended for precise radio assembly. Bits must be ordered separately.

RSX4043A Adjustable Torque Screwdriver

Insertion and Extraction Tool

Installs and/or removes wires from accessory connector.

6680163F01 Insertion and Extraction Tool



Hex L-Shaped Key Set

Recommended for front panel and PA removal/installation. 10 piece set from 1.27mm to 6mm.

0180370B87 Metric Hex L-Shaped Key Set



SPECTRA Motorcycle Radio



Service Tools, Manuals

Service Tools

Crimping Tool

For custom installations requiring crimping of Mini-UHF RF connector **6680388A26** Crimping Tool



6680388A26

RF Service Cables

3080373B25 RF Injection Board Output Cable. Connects to the RX injection output of the VCO assembly for testing RF injection level

3080373B26 BNC (M) to SMB (M) Cable

3080373B41 BNC (F) to Taiko-Denki (M) Cable

3080373B27 BNC (M) to SMB (F) Cable

0180355A28 BNC (F) to Taiko-Denki (F) Adapter

Service Tools

RF Service Cable Kit

TKN8531C Key-Variable Loader Cable

5880384G68 SMA to BNC Adapter

5880367B21 Mini-UHF Male to 'N' Female Adapter

0180386A82 Anti-Static Grounding Kit

0180320B16 Magnetic Screwdriver Set with Bits

Manuals

6880103W01 Installation/Instruction Manual

